

# CORE SERIES



## Table of contents

<b>General information</b>	<b>4</b>
<b>Installation</b>	<b>6</b>
1 Important information	6
2 Identification plate	7
3 Setting the pinlock code Core Plus	8
4 Changing the pinlock code Core Plus	9
5 Changing the pinlock code after installation Core Plus	10
6 Installation/location	11
7 Step-by-step instructions for installation	12
8 Schematic view of installation	15
9 Power adapter	16
10 Pictograms/stickers	17
<b>Use</b>	<b>18</b>
1 Opening the ARKY Core	18
2 Closing the ARKY Core	19
3 Step-by-step instructions for emergencies	20
4 After using the AED	21
5 Maintenance and cleaning	21
<b>Specifications</b>	<b>22</b>

## General information

Please read these instructions in full before installing and using the ARKY Core.

### Important

- Maintenance and installation of the ARKY Core should only be carried out by a qualified electrician for safety reasons.
- The ARKY Core should ideally be installed in a shaded location and never in full sunlight. Place the cabinet against a flat wall, taking into account the minimum clearance space and applicable fire safety regulations.

### Safety

- Ensure that the power is off when carrying out maintenance and/or when connecting the ARKY Core.
- Leave a clearance of at least 30 cm around the ARKY Core to ensure proper ventilation.
- Take into account the minimum clearance space and applicable fire safety regulations.
- Always keep the area under the ARKY Core clear.
- Do not install the ARKY Core close to radiators or other sources of heat.
- To prevent the risk of fire and electric shock, avoid naked flames in the vicinity of the ARKY Core.
- Do not insert pointed objects into the recesses/openings of the ARKY Core.

### Environment

- Do not dispose of the ARKY Core and its packaging in the household waste. Make use of the collection system available in your locality. The use of collection systems helps to preserve the environment and health.
- Use the original packaging of the ARKY Core if you wish to return it.

### Warranty


Failure to comply with the following will void any warranty, explicitly or implicitly:

- Do not remove any parts that belong to the ARKY Core.
- Do not insert objects into the openings on the ARKY Core.
- Only authorized personnel are permitted to carry out maintenance and repairs on the ARKY Core.

#### ARKY Core

##### Maximum protection for your AED

- Four small fans and one large fan
- Two heating elements with thermostat
- Electronic lock with pincode
- Internal lighting
- Acoustic alarm



# Installation


## 1 Important information

Please read these instructions in full before installing and using the ARKY Core.

**Please note**


Never install the ARKY Core in full sunlight. It should ideally be situated in a shaded location on a flat wall. Take into account the minimum clearance space and applicable fire safety regulations.

- 1 Wall section
- 2 Cap
- 3 Base
- 4 Two heating elements
- 5 Pinlock
- 6 PCB compartment



## 2 Identification plate

Always state the type designation and serial number when contacting customer service or your supplier.




Instruction pinlock ARKY Core Plus

### 3 Setting the pinlock code Arky Core Plus

**Please note**

To use the pinlock, the ARKY Core Plus must be powered by a suitable power supply.




Pinlock

**Default code: 1-5-1-5 (+OK)**

**Entering a code on the pinlock**

- **Enter the code on the pinlock.**  
Enter the correct code on the pinlock, followed by the 'OK' button. An alarm will sound and the lock will be released for 7 seconds.
- **There was an error when entering the code.**  
Press 'C'. The code can then be entered again, starting from the first digit.

- **'OK' was pressed after entering an incorrect code.**  
There will be two beeps. The code can then be entered again, starting from the first digit.
- **The pinlock was pressed in or the code was not entered in full (without pressing 'OK').**  
After 20 seconds, the entry is automatically deleted. The code can then be entered again, starting from the first digit.



PCB reset button

Instruction pinlock ARKY Core Plus

### 4 Changing the pinlock code after installation Arky Core Plus

**Tip**

Change the code before suspending the cabinet. When setting a new code, the cabinet must be supplied with power. The changed code will remain saved if the power is disconnected.

**Changing the code**

Open the cabinet with the default code (1-5-1-5 + OK). The electronics compartment at the rear of the cabinet becomes visible. Remove the transparent cover. The PCB is now accessible. Briefly press the reset button on the PCB and set a new code.

- 1** After releasing the reset button, enter the current code.
- 2** Press 'OK'.
- 3** Enter a new code.
- 4** Press 'OK'.
- 5** The new code is saved and can be used immediately.

**Conditions**

- 1** A pin code consists of between 4 and 8 numbers.
- 2** These codes will be rejected when setting a new code:
  - a** 1234
  - b** Codes starting with 4 equal numbers (0000, 1111, 222254, etc.)

Instruction pinlock ARKY Core Plus

## 5 Changing the pinlock code after attachment Arky Core Plus

To change the code after the cabinet has been suspended, carry out the following steps first:

- a** Remove the (opened) cabinet from the wall. The cabinet can be lifted slightly to allow it to be removed from the wall.
- b** Carefully set the cabinet down on the ground/ table or ask a second person to hold it.

**Please note**

Pull the power cable back from the wall at the same time to prevent tension on the cable.

- c** Carefully remove the transparent cover from the rear (see the adjacent figure).



Transparent cover

## 6 Installation/location


**Please note**

Use fixing materials that are suitable for the type of surface to which the ARKY Core is being fitted. The minimum bearing capacity required is 20 kg.

Screw diameter: max. 6 mm  
Collar diameter: max. 12 mm

**Enclosed fixing materials**

- 4 x screw
- 4 x nylon plug
- 4 x stainless steel ring



Enclosed drilling template

## 7 Step-by-step instructions for installation

- 1 Identify a suitable location for installation of the ARKY Core.

**Please note**

- a Never fit the ARKY Core in full sunlight. It should ideally be situated in a shaded location on a flat wall.
- b Take into account the minimum clearance space and applicable fire safety regulations.

- 2 Mark the attachment points and cable inlet on the wall. Use the enclosed drilling template to help you.
- 3 Place the drilling template on the wall. Ensure that the arrow is visible and pointing upwards. If necessary, fix the drilling template in place with adhesive tape.  
The recommended distance from the ground: 140 cm (see drilling template)
- 4 Use a pencil/marker to mark the holes on the wall.
- 5 Remove the drilling template from the wall.
- 6 Drill the appropriate holes according to the fixing materials selected.
  - a Based on the enclosed fixing materials: drilling diameter 8 mm
  - b Cable inlet: min. 8 mm

- 7 Fit the mounting holes with plugs (except for the cable inlet).
- 8 Insert the supplied screws into the top two mounting holes and hang the ARKY Core cabinet. Make sure that the cable does not get between the cabinet and the wall.
- 9 Route the power cable through the cable inlet and feed through as far as possible.
- 10 After feeding the electrical wire to a desired distance, attach the bottom two screws to secure the cabinet to the wall.

**Tip**

The mounting holes are visible through the transparent window on the front.

- 11 Connect the cabinet to a power source/mains using the provided power adapter.

**Please note**

Brown is + and blue is -

12 Connect the cabinet to a power source/mains using the enclosed power adapter.

**Please note**

The minimum voltage requirements for building-related installation:  
100 - 240 V/AC, 50/60Hz. **Never place the power adapter outside.**

13 If the ARKY Core has been connected correctly, the LED strip in the cabinet will light up.

14 Open the cabinet with the default code: 1-5-1-5-OK (carry out the steps outlined in section 3 if a different code is required).


15 Tighten all screws (including the top two).

16 The cabinet is installed and ready for use.

## 8 Schematic view of installation

### Schematic view of wall attachment (with enclosed fixing materials).

- A Wall
- B ARKY Core
- C Plug
- D Screw




View of wall installation cross-section

## 9 Power adapter

### Always place the power adapter indoors

- Only connect the ARKY Core to a power source/ mains grid that can be switched off and locked (always disconnect the power supply for maintenance and/or troubleshooting).
- Maintenance and installation of the ARKY Core should only be carried out by a qualified electrician.
- Ensure that the power is off when carrying out maintenance and/or when connecting the ARKY Core.



- 1 Wall
- 2 ARKY Core
- 3 Power adapter



### Please note

When setting a code other than the default code, it can be helpful to (temporarily) keep the power cable on the inside as long as possible and not to fix it with cable clips, for example, to ensure freedom of movement.

## 10 Pictograms/stickers



# Use

## 1 Opening the ARKY Core

Open the ARKY Core by entering the correct code on the pinlock, then confirm with 'OK'.

The base moves down automatically.

Centre the AED on the aluminium plate against the rear wall as soon as the base moves no further downwards.

## 2 Closing the ARKY Core

Place a hand on either side of the base and push upwards until the base locks firmly into the wall section.

1



2



3



### 3 Step-by-step instructions for emergencies

In the event of an emergency, carry out the following steps.

- 1 Call emergency services
  - Speak loudly and clearly, outline the situation and state the location.
- 2 Start resuscitation (CPR)
- 3 Open the cabinet
  - Enter the correct code and confirm with 'OK'.
- 4 Take the AED out of the cabinet
- 5 Go to the victim
- 6 Turn the AED on
- 7 Follow the instructions on the AED



CALL EMERGENCY SERVICES



START CPR



USE AED



ADVANCED CARE

### 4 After using the AED

- 1 Place the AED back in the cabinet.
- 2 Close the cabinet.
- 3 Contact your supplier.


### 5 Maintenance and cleaning

For safety reasons, maintenance and installation of the ARKY Core/connection to the mains should only be carried out by a qualified electrician. Ensure that the power is off when carrying out maintenance and/or when connecting the ARKY Core.

#### Cleaning the ARKY Core

- Clean the surfaces of the ARKY Core with a soft, damp cloth. Do not use chemical-based products or cleaning agents as these may damage the cabinet's plastic enclosure.
- Dry the ARKY Core cabinet with a soft, dry and clean cloth.
- Do not rub the cabinet with a hard object. This may permanently damage the cabinet.
- Do not use a high-pressure cleaner to clean the ARKY Core cabinet.

## Specifications



Global dimensions in mm

### Dimensions

430 x 504 x 214 mm

### Weight

4,25 kg

### Materials

Wall section:	ABS
Base:	ABS
Cover:	PETG
PCB cover:	PETG
Mounting bracket:	Aluminium
Heater pack:	Aluminium

### Power supply/voltage limits

Power adapter:

Meanwell GST120A24-P1M

Input: 100-240VAC, 50/60Hz

Output: 24V – 5.0A, 120W MAX

### Operating temperatures

The ARKY Core is designed for the protection and storage of an AED at ambient temperatures of between -30°C and +50°C.

### Heating/ventilation

The ARKY Core is equipped with five fans and two heating elements of 24 V/45 W.

#### Heating:

Switches on at <7°C

Switches off at >10°C

#### Ventilation:

Switches on at >40°C


Switches off at <35°C

### Alarm

If the correct code is entered on the pinlock (when the ARKY Core is powered by a suitable power supply), the cabinet will open and an acoustic alarm will sound. The alarm will switch off automatically after a few seconds.

### IP degree of protection

The ARKY Core has IP55 degree of protection.



Verlengde Bremenweg 12  
9723 JV Groningen  
The Netherlands

+31 (0) 50 311 60 85  
sales@arkycase.com  
arkycase.com